




LOVENSE

Ferri

USER MANUAL



English

What's Included

- (1) Bluetooth® Remote-Controlled Panty Vibrator
- (1) USB Charging Cable
- (1) User Manual
- (1) Quick Setup Guide
- (1) Storage Bag
- (1) Extra Magnetic Cap

Specifications

Materials	ABS Plastic/Body-Safe Silicone
Weight	35g
Battery	Li-Ion Rechargeable
Charging	60 Minutes
Use Time	up to 195 Minutes
Standby	up to 100 Hours
Waterproof	IPX7 Waterproof

Charging

Turn off Ferri. The cable can be plugged into any USB port or USB/AC power adapter. It will take approximately 60 minutes to fully charge. Once it is fully charged, the solid red light will turn off.

***Note:** The magnetic charger will only work if positioned correctly. If a solid red light doesn't turn on, rotate the cable 180 degrees.*

Cleaning & Care

- Clean Ferri before and after each use.
- Clean with warm water and a mild soap (or sex toy cleaner).
- Dry thoroughly before storing.

Usage Tips

- Place Ferri inside your underwear and attach the magnetic cap on the outside.
- To reduce the toy's sound in quiet areas, change your toy's maximum vibration in the app.
- Use lube at your own discretion. Only use water-based lube, as silicone or oil-based lube may affect the silicone casing.
- You can adjust the low, medium, and high levels to suit your needs.
- Once in the programming mode in our app, you can store up to 10 patterns (that you create) in Ferri.

Warning

- DO NOT boil in water (the battery may explode or water could leak into the toy).
- Keep away from extreme heat or cold.
- Make sure your toy is recharged at least once every six months.
- DO NOT use the toy while charging.
- Please make sure you don't attach the charging cable to any metal or stainless steel materials.

Links

Check out the newest guide/download links here. Our software is constantly updated.

Online guide: www.lovense.com/guide

App download: www.lovense.com/download

If you have any feedback or need any additional assistance, use the contact form at www.lovense.com/contact. Someone from the Lovense team will normally reply within 12-24 hours.

Warranty Terms & Conditions

LOVENSE warrants this product for a period of ONE (1) YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify LOVENSE during the warranty period, LOVENSE will, at its discretion, replace the product free of charge.

Visit www.lovense.com/warranty for detailed warranty and product return information.